



APRS

Pinpoint is a Windows program for APRS.



Configuration

To use with Signalink, see the Packet How-to.



Once the radio, the Signalink, and the Soundmodem are configured, start PinPoint and change these settings:

Options — □ ×

APRS TNC GPS Map APRS-IS Misc Donate

My APRS Call sign + SSID

APRS Path

Position comment

Station icon <  >

Overlay (type table + symbol directly in box + Enter key)

APRS DigiPeater settings

Enable APRS DigiPeater (Fill-in Digi. For non-KISS TNC's only for the moment)

My DigiPeater alias

APRS Position Beacons settings

Enable APRS beaoning

Beacon at least every minutes seconds

Beacon a minimum of every km

Beacon when heading changes more than degrees

Beacon my altitude

Beacon my course and speed

Maximum speed reported via radio km/h

Options

APRS TNC GPS Map APRS-IS Misc [Donate](#)

TNC type: network KISS mode

Connect TNC automatically when PinPoint starts

Serial TNC Settings

COM port: COM3 Serial Speed: 9600

Data bits: 8 Parity: None

Stop bits: 1 Flow control: Hardware

RF Speed: 1200 EOL Char: CR

Send startup script when connecting to TNC

Send shutdown script when disconnecting TNC

Network KISS TNC Settings

TCP/IP address or URL: 127.0.0.1

Port: 8100

Note how the Network Kiss Port (8100) in the PinPoint settings needed to be changed to match the SoundModem settings.