

Slow Scan TV

From  [Wikipedia: Slow-scan Television](#):

Slow Scan television (SSTV) is a picture transmission method used mainly by amateur radio operators, to transmit and receive static pictures via radio in monochrome or color.

[SSTV] is a much slower method of still picture transmission, usually taking from about eight seconds to a couple of minutes, depending on the mode used, to transmit one image frame.

Since SSTV systems operate on voice frequencies, amateurs use it on shortwave (also known as HF by amateur radio operators), VHF and UHF radio.

Android

The easiest way to start playing SSTV is to install [Robot36](#) to receive and (optionally) [SSTV Encoder](#) to send.

To test this off the air, use a phone with SSTV Encoder to “transmit” the picture as sound via the speakers, while a second phone with Robot36 listens and decodes the image.

To decode SSTV transmitted over the air, do the same thing: have your phone with Robot36 listen to the radio speaker and you'll see the image load.

Computer

The previous method is the most basic and is subject to noise from the environment. A better way of receiving and transmitting is to send the audio from the radio straight to a computer.

With the [Signalink](#) already installed and configured, the only other step is to install a program like [MMSSTV](#)



Here's a picture that VA7FI received from the ISS on Jan 1, 2020 at 7:27 on 145.800 MHz:



More information about SSTV from the ISS, can be found [here](#).