

# APRS

[Pinpoint](#) is a Windows program for APRS. 

## Configuration

To use with [Signalink](#), see the [Signalink How-to](#).



Once the radio, the Signalink, and the Soundmodem are configured, start PinPoint and change these settings:



Note:

- Network Kiss Port (8100) in the PinPoint settings needed to be changed to match the SoundModem settings.
- Also, the Serial TNC Settings don't matter since they are not being used by Network Kiss.

## SSID

You'll sometimes see a dash number after the callsign, this is called an SSID and they have different meaning depending on whether you're on APRS or Winlink. See the [SSID How-To](#) for more info.